

**Berntsen International, Inc.**  
***Marking the Boundaries of the Nations since 1972***

**MONUMENT INSTALLATION INSTRUCTIONS**

MODEL G3

MATERIALS REQUIRED FOR SETTING MONUMENT:

1. Sledgehammer (recommended: Urethane-faced deadblow sledgehammer)
2. Steel stamp set
3. F-1 Monument
4. Work gloves and proper eye protection and clothing

**\*\*IMPORTANT:** Prior to installation, stamp as much information on the marker as possible. **\*\***

**INSTALLATION**

1. Locate and clear point at which monument is to be set.
2. Place G-3 Monument at this point and prepare to begin driving into ground making certain that you are keeping the monument straight (vertical).
3. Drive monument into ground until flush (or slightly below) ground surface.
4. Stamp any final required markings (such as a +) on top surface of monument.
5. Make certain area around monument is tamped (and backfilled if necessary).
6. Make surface rubbing of top of monument if required and complete documentation in survey field note book.

*REMEMBER: "Any Monument Is Only As Good As How It Was Set".*

**QUESTIONS? PLEASE CONTACT US FOR ASSISTANCE:**

Email: [surveymark@berntsen.com](mailto:surveymark@berntsen.com)

**Toll-Free Telephone: 1-800-356-7388 (USA, Canada and Caribbean Islands)**

**Toll-Free Fax: 1-800-249-9794 (USA, Canada and Caribbean Islands)**

**Telephone: +1 608.249.8549 (all other countries)**

**Fax: +1 608.249.9794 (all other countries)**