

Berntsen International, Inc.
Marking the Boundaries of the Nations since 1972

MONUMENT INSTALLATION INSTRUCTIONS

A-TAG PAVEMENT MARKER

INSTALLATION

New Construction Tag

The A-TAG is simply placed in the soft concrete or asphalt and pushed down so it is slightly recessed.

Retrofit Tag

A hole is drilled with the diamond tipped A-TAG drill bit, then the tag is glued in place with marine epoxy. The A-TAG is counter sunk to avoid damage by snow plows.

REMEMBER: "Any Marker Is Only As Good As How It Was Set".

QUESTIONS? PLEASE CONTACT US FOR ASSISTANCE:

Email: surveymark@berntsen.com

Toll-Free Telephone: 1-800-356-7388 (USA, Canada and Caribbean Islands)

Toll-Free Fax: 1-800-249-9794 (USA, Canada and Caribbean Islands)

Telephone: +1 608.249.8549 (all other countries)

Fax: +1 608.249.9794 (all other countries)