

Berntsen International, Inc.
Marking the Boundaries of the Nations since 1972

MONUMENT INSTALLATION INSTRUCTIONS

Models BP1 & BP2

MATERIALS REQUIRED FOR SETTING MONUMENT:

- 1) BP1 Marker
- 2) Plastic expansion plug for BP1 Marker
- 3) BPM DRL drill bit
- 4) Drill
- 5) Adhesive (grout or epoxy)
- 6) Hammer (recommended: urethane or soft-faced hammer)
- 7) Work gloves and proper eye protection and clothing

INSTALLATION

1. Locate and clear point at which monument is to be set.
2. Using drill and BPM DRL drill bit, drill hole at marked point (take care to insure that the "recess" portion of the hole has been made with upper bit).
3. *OPTIONAL*: Take a small amount of adhesive and apply around plastic expansion plug.
4. Push expansion plug into drill hole.
5. If necessary, clean excess adhesive from around hole.
6. Using hammer, drive BP1 marker into expansion plug so that it is flush with the surrounding concrete.

REMEMBER: "Any Monument Is Only As Good As How It Was Set".

QUESTIONS? PLEASE CONTACT US FOR ASSISTANCE:

Email: surveymark@berntsen.com

Toll-Free Telephone: 1-800-356-7388 (USA, Canada and Caribbean Islands)

Toll-Free Fax: 1-800-249-9794 (USA, Canada and Caribbean Islands)

Telephone: +1 608.249.8549 (all other countries)

Fax: +1 608.249.9794 (all other countries)