

Berntsen International, Inc.
Marking the Boundaries of the Nations since 1972

MONUMENT INSTALLATION INSTRUCTIONS

Feno® Models F350, F600, F1000

MATERIALS REQUIRED FOR SETTING MONUMENT:

1. Feno Spike
2. Feno Tool Kit
 - a. Driver
 - b. Extension Sleeve
 - c. Ground Driving Plate
3. (OPTIONAL) Bronze or Aluminum Cap
4. (OPTIONAL) Polyroc Monument Block
5. Hammer

INSTALLATION

1. Place the marker head in the required position and drive the spike into the ground using the driving tool and a suitable hammer. **(OPTIONAL)** *Drive the spike through a Polyroc Monument Block, for better visibility.*
2. Stop driving the spike when the bottom of the driving tool handle is 1 inch (25 mm) above the top of the head of the marker (stop position) and remove the driving tool.
3. Place the sleeve down the inside of the spike.
4. Drive the sleeve downwards with the hammer. This action ensures that: a) the head of the marker is firmly held in place by a positive downward pressure; b) the driving of the strong anchor prongs into the soil will firmly anchor the spike.
5. Discontinue driving the sleeve when the base of the handle is about 1 inch (25 mm) above the top of the marker head (stop position).
6. Remove the driving tool.
7. (OPTIONAL) Tap an aluminum or bronze cap into the spike.

REMEMBER: "Any Monument Is Only As Good As How It Was Set".

QUESTIONS? PLEASE CONTACT US FOR ASSISTANCE:

Email: surveymark@berntsen.com

Toll-Free Telephone: 1-800-356-7388 (USA, Canada and Caribbean Islands)

Toll-Free Fax: 1-800-249-9794 (USA, Canada and Caribbean Islands)

Telephone: +1 608.249.8549 (all other countries)

Fax: +1 608.249.9794 (all other countries)